




## ECU : Nissan Primera 1.5



Connect as below:


Serial Suite:

ECU Plug:


Red  
Black

to  
to

1 Pins Red (Power Supply +12 Volt)  
1 Pins Black (Ground)






Where to connect the flat cable:



# READ the ECU:

You have to put 4 wire (bridge) like in the picture.



Connect the flat cable like in the picture;

## WRITE the ECU:

Then you have to put another wire (bridge) like in the picture, the flat cable is still connect.

