



# **VAG908 Driver for Windows7 x64**

## **Installation Guide**


1. Click the **Start** button, right-click **Computer**, and then click **Properties**.




## 2. Click **Device Manager**.




### 3. Double-click the device with yellow exclamation mark.




#### 4. Click **Update Driver**.




5. Click **Browse my computer for driver software.**



6. Click **Let me pick from a list of device drivers on my computer.**




7. Click **Show All Devices**, and then click **Next**.







8. Click **Have Disk**.




9. Click **Browse**.




10. Navigate to **Driver** directory (under directory of this document), select **ftdibus**, and then click **Open**.




**11. Click OK.**




12. Click **USB Serial Converter**, and then click **Next**.




**13. Click Yes.**



14. Click **Install this driver software anyway.**




**15. Click Close.**





**16. Repeat Step 3 to Step 15 for device USB Serial Port.**



**17. Installation complete.**